CSE575-Section4: MyLocation activity

I. Giving access to the location service (GPS) of Android device by adding this line of code in to the AndroidManifest.xml

```
<uses-permission android:name="android.permission.ACCESS FINE LOCATION" />
```

It should look like this AndroidManifest.xml

II. Layout activity_my_location.xml

```
<?xml version="1.0" encoding="utf-8"?>
<LinearLayout xmlns:android="http://schemas.android.com/apk/res/android"</pre>
    xmlns:app="http://schemas.android.com/apk/res-auto"
    xmlns:tools="http://schemas.android.com/tools"
    android:layout width="match parent"
    android:layout height="match parent"
    tools:context="com.tando.school.MyLocation"
    android:orientation="vertical">
    <ScrollView
        android:layout width="match parent"
        android:layout height="match parent">
        <LinearLayout</pre>
            android:layout_width="match_parent"
            android: layout height="match parent"
            android:orientation="vertical">
                android:layout width="match parent"
                android:layout height="wrap content"
                android:layout marginTop="15dp"
                android:layout_marginBottom="20dp"
                android:gravity="center"
                android:text="Current Location"
                android: textColor="#000"
                android:textSize="20dp" />
            <TextView
                android:id="@+id/txtLat"
                android:layout width="wrap content"
                android: layout height="wrap content"
                android:layout_marginLeft="15dp"
                android:layout marginTop="10dp"
                android:text="Latitude: "
                android:textColor="#000"
                android:textSize="15dp" />
            <TextView
                android:id="@+id/txtLong"
                android:layout width="wrap content"
                android:layout_height="wrap_content"
                android:layout marginLeft="15dp"
                android:layout marginTop="10dp"
```

```
android:text="Longitude: "
                android:textColor="#000"
                android:textSize="15dp" />
            <TextView
                android:id="@+id/txtAccuracy"
                android:layout width="wrap content"
                android:layout_height="wrap_content"
                android:layout marginLeft="15dp"
                android:layout marginTop="10dp"
                android:text="Accuracy: "
                android:textColor="#000"
                android:textSize="15dp" />
            <TextView
                android:id="@+id/txtAltitude"
                android:layout width="wrap content"
                android:layout height="wrap content"
                android:layout marginLeft="15dp"
                android:layout_marginTop="10dp"
                android:text="Altitude: '
                android:textColor="#000"
                android:textSize="15dp" />
            <TextView
                android:id="@+id/txtAddress"
                android:layout width="wrap content"
                android:layout_height="wrap_content"
                android:layout marginLeft="15dp"
                android:layout marginTop="10dp"
                android:text="Address: "
                android:textColor="#000"
                android:textSize="15dp" />
        </LinearLayout>
    </ScrollView>
</LinearLayout>
```

III. MyLocation.java (Explanations are in comments)

```
package com.tando.school;
import android.Manifest;
import android.content.Context;
import android.content.pm.PackageManager;
import android.location.Address;
import android.location.Geocoder;
import android.location.Location;
import android.location.LocationListener;
import android.location.LocationManager;
import android.os.Build;
import android.support.annotation.NonNull;
import android.support.v4.app.ActivityCompat;
import android.support.v4.content.ContextCompat;
import android.support.v7.app.AppCompatActivity;
import android.os.Bundle;
import android.util.Log;
import android.widget.TextView;
import java.io.IOException;
import java.util.List;
import java.util.Locale;
//Must give permission ACCESS FINE LOCATION in the manifest
```

```
public class MyLocation extends AppCompatActivity {
    // provides access to the system location services
   LocationManager locationManager;
    //Used for receiving notifications from the LocationManager when the location
has changed
   LocationListener locationListener;
    //Process when users give the permission
    @Override
   public void onRequestPermissionsResult(int requestCode, @NonNull String[]
permissions, @NonNull int[] grantResults) {
        super.onRequestPermissionsResult(requestCode, permissions, grantResults);
        //Start the location service when users allow for the location service
        if (grantResults.length > 0 && grantResults[0] ==
PackageManager. PERMISSION GRANTED) {
           startListening();
    //checking method for granted permission
   public void startListening() {
        if (ContextCompat.checkSelfPermission(this,
Manifest.permission.ACCESS FINE LOCATION) == PackageManager.PERMISSION GRANTED) {
            locationManager = (LocationManager)
this.getSystemService(Context.LOCATION SERVICE);
    //Update location method. When the user moves to another location
   public void updatedLocationInfo(Location location) {
        //testing on log
        Log.i ("Location", location.toString());
        //Cast into their IDs textviews to parse information from location service
        TextView latTextView = (TextView) findViewById(R.id.txtLat);
        TextView lonTextView = (TextView) findViewById(R.id.txtLong);
        TextView altTextView = (TextView) findViewById(R.id.txtAltitude);
        TextView accTextView = (TextView) findViewById(R.id.txtAccuracy);
        //Retrieve latitude, longtitude, altitude, accuracy from the location
service
        latTextView.setText("Latitude: " + location.getLatitude());
        lonTextView.setText("Longitude: " + location.getLongitude());
        altTextView.setText("Altitude: " + location.getAltitude());
        accTextView.setText("Accuracy: " + location.getAccuracy());
         * Create Geocoder object to Get the address
        * A class for handling geocoding and reverse geocoding. Geocoding is the
         * transforming a street address or other description of a location
         * into a (latitude, longitude) coordinate.
         * reference:
https://developer.android.com/reference/android/location/Geocoder.html
        Geocoder geocoder = new Geocoder(getApplicationContext(),
Locale.getDefault());
        //Using try/catch to prevent the app from crashing when failing to get
Addresses from Geocoder
        try {
            //Declare the error string
            String address = "Unable to get the address!";
            //Returns an array of Addresses that are known to describe the area
immediately surrounding the given latitude and longitude, return only 1 address
           List<Address> listAddresses =
geocoder.getFromLocation(location.getLatitude(), location.getLongitude(), 1);
            if (listAddresses != null && listAddresses.size() > 0) {
```


```
address = "Address: \n";
                //check for every item in the list Addresses is valid
                if (listAddresses.get(0).getSubThoroughfare() != null) {
                    address += listAddresses.get(0).getSubThoroughfare() + " ";
                //Street name
                if (listAddresses.get(0).getThoroughfare() != null) {
                    address += listAddresses.get(0).getThoroughfare() + "\n";
                //City name
                if (listAddresses.get(0).getLocality() != null) {
                    address += listAddresses.get(0).getLocality() + "\n";
                //Zip code
                if (listAddresses.get(0).getPostalCode() != null) {
                    address += listAddresses.get(0).getPostalCode() + "\n";
                //Country name
                if (listAddresses.get(0).getCountryName() != null) {
                    address += listAddresses.get(0).getCountryName() + "\n";
            TextView addressTextView = (TextView) findViewById(R.id.txtAddress);
            //set the array of address into the text View declared above
            addressTextView.setText(address);
        } catch (IOException e) {
            e.printStackTrace();
   @Override
   protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(R.layout.activity my location);
       locationManager = (LocationManager)
this.getSystemService(Context.LOCATION SERVICE);
        //Retrieve the new address list from locationManager when the users change
their location
       locationListener = new LocationListener() {
            @Override
           public void onLocationChanged(Location location) {
                //Call the updatedLocationInfo method.
                updatedLocationInfo(location);
            //These method will not be used
            @Override
           public void onStatusChanged(String provider, int status, Bundle extras)
{
            @Override
            public void onProviderEnabled(String provider) {
            }
            @Override
            public void onProviderDisabled(String provider) {
```

//Set address to empty string again when we know it is working


```
//Check for the version of SDK
        if (Build.VERSION.SDK INT < 23) {</pre>
            startListening();
        } else {
            // above 23 we need to check for permission
            if (ContextCompat.checkSelfPermission(this,
Manifest.permission.access_fine_Location) != PackageManager.permission_granted) {
                //ask for permission. Number 1 is just a request queue.
                ActivityCompat.requestPermissions(this, new
String[]{Manifest.permission.ACCESS FINE LOCATION}, 1);
            //we have permission
            else {
locationManager.requestLocationUpdates (LocationManager.GPS PROVIDER, 0, 0,
locationListener);
                //Returns a Location indicating the data from the last known
location fix obtained from the given provider
                Location location =
locationManager.getLastKnownLocation(LocationManager.GPS_PROVIDER);
                //In case location does not have lastknownlocation, we call the
updatedLocation method above
                if (location != null) {
                    updatedLocationInfo(location);
        }
   }
}
```

Demo:


1. When click on it as the first time, it will ask for a permission



2. Click allow, you will not see anything display, click the back arrow and click on the My Location section again. You will see your current location display



3. Change location to test if the app can update the location



4. The location will change when we click send (In this case I change from my house to CSUSB campus)

